

Appendix A
DiGiCo
Optocore V221
For SD Rack Optocore Operation

Issue E - May 2014

Contents (Appendix A)

A1.1 Optocore V221 - Introduction	A1-4
A1.1.1 System Overview	A1-4
A1.1.2 Opto V220 (DiGiRacks) and Opto V221 (SD Racks).....	A1-5
A1.1.3 Replacing DiGiRacks with SD Racks	A1-5
A1.1.4 Replacing SD Racks with DiGiRacks	A1-7
A2.1 The Audio IO Panel	A1-8
A2.1.1 Layout	A1-8
A2.1.2 Quick Start Guide for SD V370+ and Optocore V221.....	A1-8
A2.1.3 Audio Sync	A1-12
A2.1.4 The Port List	A1-12
A2.1.5 Managing Ports	A1-12
A2.1.6 SD Rack Splits	A1-13
A3.1 SD Series Dual Loop Optocore Systems	A1-13
A3.1.1 Important Considerations	A1-13
A3.2.1 Setting up a Dual Loop System	A1-14
A3.2.2 Console Snd/Rcv Ports	A1-14
A3.2.3 Single Loop Console on Loop 2	A1-15

A1.1 Optocore V221 - Introduction

A1.1.1 System Overview

The new V221 DiGiCo Optocore fibre system provides users with a highly flexible system. In order for correct and safe operation of the system, the basic principles need to be understood.

A DiGiCo fibre loop now supports up to 10 SD Engines (5 Redundant Consoles) and 14 Racks. These are identified as follows.

NOTE: For more information on Dual Loop Optocore systems please refer to the relevant section of this Appendix

SD Engines are allocated ID's between 1 and 10. SD7 Consoles with 2 Engines are allocated ID's in consecutive pairs.. 1&2, 3&4 etc. SD8 Consoles only have a single Engine and therefore only have a single ID. If 2 SD8's are to be configured as a redundant pair, then their ID's should be allocated consecutively, in the same way that SD7 redundant Engines are paired.

SD Racks (and Optocore enabled D-Racks) are allocated ID's between 11 and 24

NOTE: SD Racks can be set to Opto IDs 1 to 10 but the racks will not work on the Optocore loop if set to these values. These values are used for factory testing only

As with previous Optocore systems, each device must have a unique ID. Additionally, each device must also be set to run at the same speed. The previous Optocore system was fixed at 1G. The default speed for the new system is 2G.

Each Optocore loop (running at 2G) is capable of 504 channels of audio at either 48k or 96k. On an SD7, up to 2 loops can be operated, providing up to 1008 channels of Optocore I/O

The Optocore Interface card (between Optocore connected devices and the SD Engine) supports 496 Input and 496 Outputs. Inter-console IO is also catered for, allowing the transmission of Audio and Video between SD Engines.

This Optocore system allows for many more channels of audio than can be simultaneously routed into and out of the console. The limit of simultaneously routed signals is 384 inputs and 384 outputs, including routing to local IO and MAD1 connected devices.

The V221 Optocore implementation provides additional functionality and features over the original Optocore system, as follows.

All inputs (to racks) are available to all consoles. However, it is possible for any console to opt-out of inputs, on a per-input card basis. This means that when the channel routing panel is then opened, only the relevant inputs are accessible. This is particularly in a larger shared system.

Output cards can be allocated / assigned to individual consoles. In practice, this allows a number of consoles sharing a single SD Rack to have an output card each.

The Optocore system can be "locked" by any console, and reconfiguring of the system is then not possible until all consoles have been placed in an unlocked state. Within a large shared system, this protection mechanism ensures that audio cannot be disrupted by another console on the loop.

In order to configure these allocations, the Optocore system has to be mapped. This map tells each device on the loop which fibre channels it is accessing – either to insert audio onto the loop or to extract audio from the loop.

Racks take audio in from external sources and insert them onto the loop. Consoles then extract this audio, which become the inputs into the console

Consoles route signals out to the loop (so insert audio onto the loop) and then racks extract this to route out to external devices.

In order for this to operate correctly, a map is built telling each device where it inserts signals onto the loop, and where it extracts audio from the loop.

The process of building this map has been made as simple as possible, and can be reduced to a few basic steps.

Connect the Consoles and Racks together, as required.

Input cards on the racks must be installed in a single block with no gaps between input cards. (So if your SD Rack only needs 5 input cards, they must occupy the first 5 slots in the rack)

On every console (SD Engine), open Audio IO and press the "Conform All Ports". This then will populate the Audio IO panel with all the connected devices. Every console must have the same Audio IO panel configuration.

Allocate Rack output cards to consoles as required.

Press the "Remap All Optocore" button.

Please carefully follow the procedure in the Quick Start section later in this manual.

A1.1.2 Opto V220 (DiGiRacks) and Opto V221 (SD Racks)

SD Series consoles are now capable of operating with either one of two different Optocore firmware versions - V220 and V221. V220 is compatible with DiGiRacks and MiNiRacks and cannot be used with SD Racks or DRacks. V221 is compatible with SD Racks and DRacks and cannot be used with DiGiRacks and MiNiRacks.

Note: Any type of rack can be used with an SD Series console if it is connected with Coaxial BNC MADI irrespective of the Optocore version that the console is using.

Sessions that have been created using Optocore connected DiGiRacks and MiNiRacks can be used with SD Racks and DRacks but a procedure must be followed to achieve this.

Sessions created using Optocore connected SD Racks and DRacks can also be used with DiGiRacks and MiNiRacks but this also involves a "conversion" procedure.

A1.1.3 Replacing DiGiRacks with SD Racks

If you are connecting racks with Optocore and your session originally used DiGiRacks or MiNiRacks, you can replace these with Optocore connected SD Racks as follows:

- 1) Ensure that the SD Series console is running **Optocore Firmware V221** (See Technical Note 252)
- 2) In SD software V370+, load the session and open the Snapshot panel.
- 3) Make a snapshot (to save all routing, input gains and other rack parameters) and ensure that the Recall Scope can recall all of this information.
To do this both Global and Recall Scopes should have Input and Output channels and Input and Output Devices ticked for all relevant input and output routes.
- 4) Open the Setup/Audio IO panel on the Master screen
- 5) Select the Opto ports (usually ports 5 and 6 which will be set as DiGiRacks) and set them to be SDRack, and set Optocore ID if required.
The Optocore IDs will have the following equivalents by default:
DiGiRack ID30 = SD Rack ID17
DiGiRack ID31 = SD Rack ID18
DiGiRack ID32 = SD Rack ID19
DiGiRack ID33 = SD Rack ID20
- 6) Manually (or automatically if connected) conform the racks to match the previous hardware setup.
- 7) Recall the snapshot – this should reinstate all the routing lost when the DiGiRacks were converted to SD Racks
- 8) Check sync is set to Optocore
- 9) Ensure that the required rack output cards are assigned to your console Optocore ID number (2.1.2 Quick Start Guide)
- 10) Save session as a New File

To run the console at 96KHz, two MADI Ports are required per 56 channel MADI stream

To convert the session to 96KHz (optional)

- 1) Make sure that MADI Ports 1-4 are all defined as DiGiRacks
- 2) Open Session structure and select 96K sample rate with appropriate mode eg 96 busses mode and Restructure
- 3) When you open Audio IO, you should now see 2 MADI Ports.. 1 : MADI 1/2 & 2 : MADI 3/4 .
Ports 5 and 6 should remain as the SD Racks (as set above)
- 4) Save session as a New File

Device Type=DiGiRack
Change to SD Rack

Connection cannot be changed at this time

Was Opto ID 30
Now Opto ID 17



After creating a new Snapshot - Change Device Type to SD Rack



Now Conform this rack to recreate I/O cards and recall the snapshot to reinstate input gains etc



A1.1.4 Replacing SD Racks with DiGiRacks

If you are connecting racks with Optocore and your session originally used SD Racks, you can replace these with Optocore connected DiGiRacks or MiNiRacks as follows:

Note: Optocore V220 cannot run at 96Khz.

If you intend to use a 96Khz SD Rack (V221) session with DiGiRacks (V220) then the session should be Restructured at 48KHz and saved as a New File before attempting to downgrade the Optocore Firmware and proceeding.

- 1) Ensure that the SD Series console is running **Optocore Firmware V220** (See Technical Note 252)
- 2) In SD software V370+, load the session and open the Snapshot panel.
- 3) Make a snapshot (to save all routing, input gains and other rack parameters) and ensure that the Recall Scope can recall all of this information.
To do this both Global and Recall Scopes should have Input and Output channels and Input and Output Devices ticked for all relevant input and output routes.
- 4) Open the Setup/Audio IO panel on the Master screen
- 5) Select the Opto ports (usually ports 5 and 6 which will be set as SD Racks) and set them to be DiGiRacks, and set Optocore ID if required.

Note: In Optocore V220, racks can only have Optocore IDs in the range of 30 to 33 and therefore if your SD Racks had V221 Optocore IDs outside of the range from 17 to 20, they will need to be changed.

The Optocore IDs will the following equivalents:

V221 >> V220

- ID 1.11 = ID 1.2A (Not valid in V220)
- ID 1.12 = ID 1.2B (Not valid in V220)
- ID 1.13 = ID 1.2C (Not valid in V220)
- ID 1.14 = ID 1.2D (Not valid in V220)
- ID 1.15 = ID 1.2E (Not valid in V220)
- ID 1.16 = ID 1.2F (Not valid in V220)
- ID 1.17 = ID 1.30**
- ID 1.18 = ID 1.31**
- ID 1.19 = ID 1.32**
- ID 1.20 = ID 1.33**
- ID 1.21 = ID 1.34 (Not valid in V220)
- ID 1.22 = ID 1.35 (Not valid in V220)
- ID 1.23 = ID 1.36 (Not valid in V220)
- ID 1.24 = ID 1.37 (Not valid in V220)

- 6) Manually (or automatically if connected) conform the racks to match the previous hardware setup.
- 7) Recall the snapshot – this should reinstate all the routing lost when the SD Racks were converted to DiGiRacks.
- 8) Check sync is set to Optocore
- 9) Save session as a New File

A2.1 The Audio IO Panel

A2.1.1 Layout

Rack hardware status

Port List
Press Button to Select

Card status for optocore
Green tick = This console
Red Cross = Available
Red Cross Greyed Out = Unavailable
NOTE - Output cards can only be taken if no other console has them

Adds Ports and Confirms all connected racks at the same time

Prevents changes to optocore settings on all consoles in the system

Select one of these 3 buttons to view relevant details

Rack details

Indicates card type and which Opto ID has ownership of Output cards

Assign or Disable all Optocore Inputs or Outputs on selected rack for this console

Remaps Inputs to Local console only

Optocore Remap button - should be used if a message appears indicating "Remap Required"

A2.1.2 Quick Start Guide for SD V370+ and Optocore V221

Switch on all consoles and SD Racks and ensure that each device has a unique Optocore ID. The console's ID is displayed in either Status Bar on the Master Screen, the Network Panel or on the Meter Bridge of an SD7. If you need to change an ID of an SD console, you will need to power cycle the SD console once the ID change has been made.

Optocore ID

Console Network

network status: **MIRRORED** Optocore ID **3**

transfer / mirror audio

A Console: SD7 (console001) [192.168.2.21]
Session:
File: d:\projects\369\mons day 4.ses
File date:
Status: MASTER MIRRORED **OK** **Audio Master**

B Console: SD7 B (CONSOLE002) [192.168.2.22]
Session:
File: d:\projects\369\mons day 4.ses
File date:
Status: STANDBY MIRRORED **OK** **Audio Master**

REMOTES

- mirrored
- mirrored
- off-line
- off-line
- off-line

session transfer

- Send Session to Selected
- Receive Session from Selected
- mirror
- Mirror to Selected
- Mirror from Selected
- Unmirror Selected

All SD hardware must be running with the same Fibre Speed. The default setting is 2G. The Current Setting can be found in either the Audio I/O panel or in the Optocore Diagnostics Panel. On an SD Rack, navigate to the Fibre Speed menu to check.

Audio I/O Panel
Optocore Setup
Fibre Speed



Connect all consoles and racks ensuring all Fibre connections are A to B.

Go to Files/Session Structure.

1) Select the appropriate Session Sample Rate using the buttons at the top of the panel:

48Khz - 128 Busses available

96KHz - 64 Busses available

96KHz - 96 Busses available


96KHz - 128 Busses available

The number of busses available is the total of Aux Busses and Group Busses used in your session.

2) Select the number of input channels, busses etc as required

3) Press the Restructure button to create your session.


4) Save your session when prompted to do so.



Select Session
Sample Rate

DiGiCo Optocore V221

Next, go to Setup/Audio Sync and set sync to Optocore. Please note that all consoles on the network must be running at the same sample rate.




Once all hardware is connected, go to System/Diagnostics/Optocore. This will list all connected Optocore devices either SDeng (console engines) to SDrack (SD Rack or D Rack) by ID. If any expected devices are not listed, please check all physical connections, Optocore ID's and Fibre Speeds. Once all devices are present, close the Diagnostics panel.

IMPORTANT NOTE: THE FOLLOWING INSTRUCTIONS DESCRIBE HOW TO AUTOMATICALLY CONFORM ALL THE RACK PORTS PRESENT IN THE SYSTEM. IF YOU ADD AND CONFORM THESE PORTS MANUALLY IT IS ADVISABLE TO LEAVE THE EXISTING MADI PORTS IN PLACE AND ADD NEW PORTS FOR OPTOCORE RACKS. THE MADI PORTS ALWAYS EXIST IN HARDWARE ON THE CONSOLE SO THEY SHOULD BE LEFT AVAILABLE FOR USE IN THE AUDIO I/O PANEL.

If the system only consists of a single SD Console:-

On an SD7, save your session, then open the Network panel, send the session to the second console engine and then mirror the two engines.

Go to Setup/Audio I/O. Press the Setup Optocore button and the Single Console button will be shown with a bright red background. Press this button, press Yes at the confirmation stage and the console will create ports for all connected racks, allocate all output cards to your console and create the Optocore map. The system is now ready to use.



If there is more than one SD Console present in the system:-

Go to Setup/Audio I/O. Press Conform All Ports and Yes in the confirmation box. The console will now interrogate the system, create ports and conform all connected SD or D Racks. A green OK should appear next to each port along with the rack type and it's Optocore ID.

On an SD7, save your session, then open the Network panel, send the session to the second console engine and then mirror the two engines.

Repeat this process for all consoles in the system.

NOTE - All consoles connected to the system MUST have all Optocore connected Racks declared in the Audio I/O

Press Setup Optocore. This opens the panel and allows the allocation of Output Cards. The Box under each card displays one of four states.

- Allocated to this console and can be changed
- Allocated to this console and cannot be changed
- Not allocated to this console and can be changed
- Not allocated to this console and cannot be changed

If an output card has been allocated to a console, the Consoles ID will be shown at the bottom of the card. The only way to release an allocation is from the Audio I/O panel of the console it is allocated to.

NOTE: Changing card allocations with these buttons is only possible if the Optocore Setup button is pressed first

NOTE: You may choose to remove all existing output card allocations before making new ones but please be aware that this will affect all allocations on all connected consoles thus potentially removing allocations already made by other users.

To do this press the Optocore Details button in the Optocore Setup panel and then press the **Clear All Outputs** button.

The **Broadcast All Output ID's** button will broadcast **all the output allocations for all consoles** from the current console to all other consoles in the system and overwrite their allocations. Once this operation is initiated, there is no way to recover the other consoles original allocations.

The **Broadcast Only My Output ID's** button will broadcast **all the output allocations for the local console** from the current console to all other consoles in the system and overwrite their allocations. Once this operation is initiated, there is no way to recover the other consoles original allocations.

IMPORTANT: Only use these functions if absolutely necessary as their action is non recoverable.

The screenshot shows the 'Optocore Details' window with a table of input and output cards. Below the table, there are summary statistics for two loops and control buttons. An arrow points from the 'Clear All Outputs' button to the text 'Clear all Output allocations on all connected consoles'. Another arrow points from the 'Broadcast All Output IDs' and 'Broadcast Only My Output IDs' buttons to the text 'Options to send output allocation information to other consoles'.

		input cards							engine ID » output cards							
ID	name	ok	1	2	3	4	5	6	7	1	2	3	4	5	6	7
1.11	5:Rack 1.11	ok	mic	mic	mic	mic				9» lin	9» lin	1» lin				
1.13	6:Rack 1.13	ok	mic	9» lin	9» lin	1» lin	1» lin									
1.15	7:Rack 1.15	ok	mic	9» lin												
1.16	8:Rack 1.16	ok	mic	9» lin	9» lin	9» lin	1» lin	1» lin	1» lin	1» lin						
1.20	9:Rack 1.20	ok	mic	mic	mic	mic	mic									
1.23	10:Rack 1.23	ok								9» lin	9» lin	9» lin	1» lin	1» lin	1» aes0	1» aes0

totals: inputs outputs available (fibre) speed max length

Loop 1: 224 176 48 2Gb 350m

Loop 2: 0 0 448 2Gb 350m

available (engine): 224 360 sample rate 96000 Hz

Buttons: Broadcast All Output IDs, Broadcast Only My Output IDs, Clear All Outputs, Close

Once you have made your output allocations, the Optocore Map needs to be created. This is done by pressing the **Remap All Optocore** button. This requires a confirmation and will cause a small interruption to any audio passing through the system. The pressing of Remap All Optocore will instruct all connected consoles and racks to update their own Maps. Any change in Output allocations or the addition of any optically connected equipment will require the Map to be updated. When this is required, The background of the Remap All Optocore button will go bright red and Remap Required will appear underneath the button.

NOTE - If any console in the system has its Lock Optocore button pressed, the re-allocation of output cards and Remap Optocore Functions are disabled.

The screenshot shows a control panel with a label 'to match connected' and a large orange button labeled 'Optocore Locked'. To the right is a keypad with buttons numbered 1 through 10. Above the keypad, it says 'Optocore IDs Locked'.

Within the Setup Optocore panel is Optocore Details. This Panel will give an overview of all connected audio I/O, output card allocations, available fibre channels (on both Loop 1 & loop 2) and available engine/Optocore interface channels. It also shows the current system Fibre speed and Sample rate.


This is a full screenshot of the 'Optocore Details' window, identical to the one shown in the previous image, displaying the table of input and output cards, summary statistics for two loops, and control buttons.

A2.1.3 Audio Sync

In standard operation, all Optocore connected console engines should be set to **Audio Sync = Optocore**. In this situation the Optocore device with the lowest Optocore ID will automatically become the Master Sync source for the Optocore system. An Optocore system can be synced to an external Word Clock sync source by connecting that Word Clock source to any SD engine Word Clock Input and selecting Word Clock as the Sync source in the Setup/Audio Sync panel.

NOTE: If 2 SD engines have Word Clock connected to them, the system will sync to the Word Clocked engine with the lowest Optocore ID


An Optocore system can also be synced to a Word Clock source connected to the Word Clock input on any SD Rack. Connecting the Word Clock to the rack automatically sets this as the Master Sync Source. If any SD engine has a Word Clock sync source and is set to Word Clock sync, this will be used as the Master Sync Source instead of the SD rack.



A2.1.4 The Port List

The Port List indicates the status of the racks connected to each port.

Any red entries in the Hardware connected columns indicate either a mismatch in Rack card contents or in the Optocore map. There is also a column to indicate the Shared Status of each rack which can be set by pressing the **Splits and Sharing** button at the bottom of the Audio I/O panel, selecting the relevant rack from the Ports List and then using the **Selected Rack Shared** buttons.



A2.1.5 Managing Ports



The simplest way to set up a system is to automatically Conform All Ports and all relevant Ports will be created. However, Ports can be manually added and removed using the Add Port and Remove Port buttons. Pressing the Add Port button provides a list of Port types to choose from. There are different rack types and also Opto Send and Receive Ports.

Console Opto Send and Receive Ports

Creating a Console Opto Send Port enables video (SD7 only) and up to 56 channels of audio to be sent between SD engines. A default port will consist of one video stream (1 rack card - 8 sockets) and 8 sockets of audio outs. When a Console Opto Send Port is created, matching Console Opto Receive Ports must also be created on all other consoles in the system.

The simplest way to create the Console Opto Receive Ports is to press the Conform All Ports button on all the other consoles and this will automatically create the relevant Receive Ports,

IMPORTANT: When these Ports are added an Optocore Remap is required and this will only work correctly if all the consoles in the system have matching Send and Receive Ports.

A2.1.6 SD Rack Splits

The SD Rack offers 2 dedicated Split outputs - Main and Aux plus the ability to split any input card to any output card.

If the rack is running at 48KHz, each rack split output provides a 48KHz Split.

If the rack is running at 96KHz the Main split output provides 96KHz channels 1-28 and the Aux split output provides 96KHz channels 29-56.

Alternatively, If the rack is running at 96KHz each split output can provide 56 channels at 48KHz.


The setting of these modes can only be adjusted on the SD Rack itself - please see the SD Rack documentation for details.

Each split can have automatic Gain Tracking that will compensate the output level for any changes in the relevant input gain.

All of these functions can be controlled on the rack itself through its own menu system but the console Audio I/O panel can also be used.

Be very careful when adjusting these parameters because they will obviously have a potentially dramatic effect on the rack's functionality.

NOTE: A card split cannot be activated if the relevant output card has already been allocated to Optocore - it must be released by the console that it using it first.



A3.1 SD Series Dual Loop Optocore Systems

A3.1.1 Important Considerations

The SD Series Optocore implementation is designed to allow 2 independent fibre loops to exist, with up to 14 SD Racks and 504 Channels of audio per loop at both 48K and 96K. This results in any dual loop console having access to 1008 Channels of IO, from up to 28 IO locations across the 2 loops.

Both the SD7 and SD5 have the ability to have 2 Optocore loops fitted.

When using a dual loop system, the following stipulations apply:-

NOTE: Dual loop consoles must have the lowest ID's in the system

In a system consisting of a dual loop SD7 and two Single loop SD10s, the SD7 Optocore Network ID must be 1+2. The SD10s can be set to any other primary ID eg 3, 5, 7 or 9.

In a system with two dual loop SD7s and two single loop SD10s, the 2 SD7s would have to have Optocore Network IDs of 1+2 & 3+4 and the SD10s would have IDs of either 5, 7 or 9.

NOTE: Loop 1 and Loop 2 must be independent

Loop 1 and Loop 2 fibres cannot be mixed. Anything connected to loop 1 can only exist on loop 1 and anything connected to loop 2 can only be connected to loop 2.

NOTE: There can only be one Loop 2

In a multi console, dual loop system, anything connected to loop 2 on one console must be present on loop 2 of all other consoles in the system. Each console cannot have its own independent loop 2 connection.

Engine input and output limits

The Optocore system can create a map for 1008 channels of audio across the two loops, however each engine can only have access to 496 inputs and 496 outputs across the 2 loops. Which inputs/outputs each console has access to is set in the Audio IO page.

A3.2.1 Setting up a Dual Loop System

Each console and rack should have its Optocore network ID set accordingly. If a Dual loop console is ID 1, it will be ID 1 on both loops. Racks can only exist on either loop 1 or loop 2 therefore their physical presence on the loop determines which loop they are on. Pressing conform all ports in Audio IO will assign Rack IDs to either loop 1 or loop 2.

The picture below shows the Audio IO from a dual loop SD7 once all ports have been conformed and the system mapped.



Racks on Loop 1 have IDs 1.XX and racks on loop 2 have IDs 2.XX



The Optocore Details Panel (shown above) shows the number of inputs and outputs mapped on each loop, the number of fibre channels available on each loop and the number of engine inputs and engine outputs remaining.

A3.2.3 Console Snd/Rcv Ports

Each console can create an opto snd port for each loop and can also separate opto rcv ports for each loop.

The picture below shows ID 1 having a snd port for both loop 1 and loop 2 and rcv ports form ID3 on loop 1 and ID 5 on loop 2.




A dual loop console can have 2 snd ports (one per loop) and upto 8 Rcv ports (4 per loop). Console Snd/Rcv ports will use up some of your 1008 optocore channels and also Engine input and output resources.

A3.2.4 Single Loop Console on Loop 2

SD8, SD9, SD10 and SD11 consoles are only able to have connections fitted one loop and the internal connections within the console will be to loop 1.

In the Options>Console menu, the Enable Optocore option allows the console to either be a loop 1 console or loop 2 console (shown below) without having to alter the internal connections.



Single loop consoles operate independently on each loop. For example, a system can exist of a dual loop SD7 (IDs 1+2), an SD8 (ID3) on loop 1 and an SD10 (also ID3) on loop 2.

SD5s & SD7s that only have a single loop fitted can also set to operate on either Loop 1 or Loop 2.